




# MIR Series Wafer type Butterfly Valve

**The instruction for installment  
service and use**

**Read the instruction carefully before installment and use**

With over 70 years of experience,  
we can offer you the best service.



## Catalogues

<b>1 General Rule</b>	<b>1</b>
1.1 Special Prompt	1
1.2 Important notice	1
1.3 Open and inspect	1
1.4 Packing parts	1
1.5 Warning	1
1.6 Designation strip	1
1.7 Operating instructions	2
<b>2 Installment</b>	<b>3</b>
<b>3 Maintenance</b>	<b>6</b>
3.1 Outline	6
3.2 Dismounting valve	6
3.3 Valve seat replacement	6
3.4 Axis seal replacement	7
3.5 Valve disassembly	8
3.6 Valve assembly	8
<b>4 Valve test procedures</b>	<b>9</b>
<b>5 Actuator installment</b>	<b>9</b>
5.1 Warning	9
5.2 The installment and adjustment of actuator	9
5.3 Actuator type	11
5.3.1 The actuator of GT Series 90° rotary valve	11
5.3.2 The actuator of AP Series 90° rotary valve	16
5.4 Handwheel	20
<b>6 Maintenance package/spare parts</b>	<b>21</b>

## 1. General Rule

Thank you for purchasing and using HLV control valve products, please read the instruction carefully before using, and this booklet including the important content of installment, service and use of the HLV MIR wafer type butterfly valve, please preserve it and that you can refer in the future.

HLV MIR type wafer valve is a high performance butterfly valve design, and the rated value of the biggest closure pressure is decided by the material.

### 1.1 Special Prompt

In order to understand easily and catch your attention, regarding the information of product safety and some important things, we will mention in this chapter or the other chapter through the following rank and special warning to you, those special warning is showed as follows.

**Careful** It means safety or other contents which must be paid Attention to.

**Attention** It means should pay attention to the mild danger.

**Warning** It means should pay attention to the moderate Danger.

**Forbidden** It shows the dangerous operation should be Forbidden.

In this chapter the security information which provided for you is not complete, in order to your security and benefit, we arrange security information of the partial products to the behind chapter of the manual depending on the need, no matter the security information is showed in any charter, you should read carefully.

At the meanwhile, except the special notice, you also should read the other contents of the manual carefully.

### 1.2 Important notice

#### 1.2.1 Operator:


**Attention** Only the qualified or the experienced personnel can install, operate and maintain MIR type control valve.

#### 1.2.2 Move, Transport, Storage

**Attention** Attention: when store and transport the products, don't invert the packing case, when open the packing case please check the product whether is consistent to the order or not, if you have any question, please connect with the company immediately, If the product is unmistakable, please read all user's material which attached with the product carefully, and should understand the application method and notice of the product.

If you store and transport product after opening the packing case, please avoid being showed under the open-air environment, prevent rusting. When lifting, please pay attention to the bearing point of the product and lift according to the identification of the product.(Fig.1)

**Forbidden** please pay attention to the weight in the packing case, when storing and transporting, the carrying capacity of the machine which transports must be bigger than the weight of the packing case certainly, and Please don't approach to the packing case, for avoiding personnel injury. (Fig.1 B)




### 1.3 Open and inspect

#### Attention

1. Open the case according to the instruction direction in the packing case.
2. Please check the product model whether is consistent to the order or not, if you have any question, please connect with the company immediately.
3. After checking up, please be sure to damage or missing with the Products and accessories.

#### Careful

Pay attention to the items that way cause injury, as nail, wood edge, Before opening the packing case.(Fig.2)



### 1.4 Packing parts

1. The main part of the products, the model which you need will be narrated in the following chapter.

#### 2. Accessory

The flange, the bolt (provides flange by your specific request) offer user's instruction booklet, and product certificate. (Fig.3)

**Attention** The other accessories take the object product as actual, Because the product model is different.



### 1.5 Warning

Safety first! Please clarify the following question before dismantling the valve from the pipeline and decomposing.

#### 1. What's the medium in the pipeline?

Make sure that what's medium in the pipeline. If has any questions, may clarify to the concerned manager.

#### 2. Have you carried on the protection?

In order to prevent injuring from special medium in pipeline, it usually requests to wear corresponding working clothes and the protection appliance.

#### 3. Whether the pipeline has reduced pressure?

Releases the pipeline pressure and removes the piping system medium. The eccentric shaft of wafer type butterfly valve form a bigger butterfly board area in an axis side, this meant that without handle or in the drive situation, when inlays a side bearing, the valve will open.

#### 4. Whether the valve is closed?

Close the valve completely at first when installing or disassembling the valve from the pipeline, the wafer butterfly valve has to dismantle in the off-position from the pipeline. To prevent the seal edge of butterfly board damaging, the flat potential plane or the axis peak shape line has indicated the Butterfly board position. (Fig.4)

### 1.6 Designation strip explanation

#### Designation strip explanation

<b>HLV</b>	
HLV FLOW MACHINERY	
TAG NO.	
MODEL NO.	
DN	mm
PN	bar
BODY-TYPE	
KV	
SP. RANG	
ACTION	
STROKE	mm
SIGNAL-RANGE	bar
S. RNO.	
DATE	

#### Certificate explanation

<p>GUARANTEE OF QUALITY</p> <p><b>HLV</b> HLV FLOW MACHINERY</p> <p>MIL/MIR SERIES</p> <p>Ours that goods are made of best materials, with first class workmanship, brand new, unused and correspond in all respects with the quality, specifications and performance as stipulated in the technical agreement of the contract.</p> <p>HLV FLOW MACHINERY CO., LTD.</p>
---

<p>NOTICE ITEMS</p> <p>1. The control valve must be installed strictly according to the engineering and the control system requirements, otherwise the serious accident will cause the person injury by fire, explosion, and poison.</p> <p>2. If the working condition of the valve components exceeded the permissive limit pressure concerning the size or the measures on the tag, which may result in serious damage and person injury by sudden release pressure in the pipe.</p> <p>3. To prevent this kind of events, a safety valve must be installed for over-pressure and protection in accordance with the government or the present industry laws.</p> <p>HLV FLOW MACHINERY CO., LTD.</p>
---

## 1. 7 Operating instructions

You should understand the rated value in each valve product label. The valve's rated value in using can't surpass the value on the designation strip.

### Eccentric shaft design

The outstanding performance of the wafer butterfly valve is the eccentric shaft design. Manifests to clamps the type valve outstanding performance a design characteristic is the eccentric shaft design. Axis bias to two planes: (

1) deviates in the butterfly board the core and (2) lags Yu Dieban to seal the plane (to see Figure 3) the eccentric shaft design to cause the rotation the butterfly board picture "the cam" equally to be separated from the valve seat to after, completely eliminates usually in the valve seat peak and the bottom end attrition spot, the butterfly board is separated from the valve Seat only to revolve along 90 eccentric arcs.

### Stop block

In order to prevent the butterfly board closure excessively to damage the valve seat (usually occurs at install handwheel or drive sets), the wafer type butterfly has design the "stopper". The stopper may also use for adjustment the localization position of the drive set online. The stopper position see (Fig.4B)


### Drive type

Handwheel, pneumatic actuator and electrical actuator, etc.

### Wafer type body design

The purpose of flange bolt hole or slot existing on some valve bodys with wafer constructions(chart 4A), is for fastening, and aligning correctly when fitting main pipes, the purpose of alignment hole/slot of wafer valve body is not for bearing the pressure from pipe, just for connecting pipe flange which is by bolts connection totally.

Fig.4





## 2 Installment

### Attention

The control valve must be installed strictly according to the engineering and the control system requirements, otherwise the serious accident will cause the person injury by fire, explosion, and poison, if the working condition of the valve components exceeded the permissive limit pressure concerning to the size or the measures on the tag, which maybe result in serious damage and person injury by sudden release pressure in the pipe. To prevent this kind of events, a safety valve must be installed for over-pressure and protection in accordance with the government or the present industry laws.

### Attention

When ordering, the valve disposes various of structural material is according to the specific pressure, the temperature, the pressure and the control current capacity condition to choose, because certain valve bodies and the valve components combination material has the certain limit of the pressure and the temperature range aspect, therefore, please don't apply these valves to the other conditions before without consulting the opinion of the sale-officer or technical department of the HLV flow machinery corporation.

1. Before install the valve, inspects the valve and the correlate equipment, look whether damaged or any sundries, guarantee the valve interior clearly and hasn't any sundries in the pipeline.
2. The control valve can be installed at any position, except there are some shockproof rules, but in general, it's usually installed the actuating mechanism vertically above the valve, because other positions may cause non-uniformity attrition and unsuitable operation to the plug and the valve cage. Regarding certain valves, it will need the strut supporting if the actuating mechanism isn't vertical (See Fig5). Please consult with the sale-office or technical department of the HLV Flow Machinery Corporation if you Want more detailed information about it.
3. When installing the valve in the pipeline, please adopt the recognized matching tube and the welding methods. During welding, the components of internal elastic may remain in the original position(Neither take them down nor move). If the process of the check-up and maintenance need successive operation, a pass-way tee valve is required to be installed Around the control valve.
4. To the structure of the leakage outside-vent type bonnet, taking the tube caulking down then connect it to the drainage pipeline. If the process of the check-up and maintenance need successive operation, a pass-way tee valve is required to be installed around the control valve.
5. Leakage of padding will lead to personnel injury. The valve padding must be fastened before leaving the factory, however, it needs readjust the padding, so as to satisfy the corresponding application conditions.
6. When install the control valve, it requires to consider about the possibility of site maintenance and daily disassemble-maintenance, well positioned, accessible. Simultaneously, it also requires to consider about the space, gap and convenience for maintaining the valve. Generally,  $H_1 = H_0 + 300\text{mm}$ ,  $H_2 = 2H_0 + 200\text{mm}$  (Fig.5).

### Attention

The actuator should be avoided in the high temperature, when the temperature is above  $62^{\circ}\text{C}$ , the membrane, sealing parts, electrical parts such as positioner will be affected in accuracy.


Under the condition of vibration, the pipe's vibration will resulted in the position deviation, so the flexibility must be ensured with the air pipe connecting to the actuating parts, the liquid pressure pipe and the electrical joints, but is less to the plastic pipe except for the loosen parts, meanwhile more necessary to the metal pipe that supposed to be fixed under vibrating Conditions, the electrical joints could be depend on the reality.

According to the material of the valves, it maybe need heat treatment after the process of welding. If so, that will cause the damage to the inner springs and plastic or inner mental units. The thermal accessories and screw joints also could be affected to looseness. Generally, you should move away the inner parts in the processing of the heat treatment after welding. Please contact the manufacturer for details.

Fig.5

Correct installment position

Match AP type actuator



Match GT type actuator






Fig.6

Body section



No.	Name
1	Bonnet
2	Seal gasket
3	Bady
4	Hoop
5	Socket hexagon bolt
6	Oring
7	Oring
8	Seat
9	Disc
10	Guided set
11	Packing
12	Gland
13	Hex nut
14	Double armed bolt
15	Axle
16	Cup head pin
17	back shaft
18	Guided set
19	Socket hexagon bolt
20	Located piece
21	Socket hexagon bolt







Fig.7

Valve section



No.	Name
1	Bonnt
2	Seal gasket
3	Bady
4	Hoop
5	Socket hexagon bolt
6	Oring
7	Oring
8	Seat
9	Disc
10	Guided set
11	Packing
12	Gland
13	Hex nut
14	Double armed bolt
15	Axle
16	Cup head pin
17	back shaft
18	Guided set
19	Socket hexagon bolt
20	Located piece
21	Socket hexagon bolt
22	Bolt
23	Yoke

In order to reduce the torque, the wafer type butterfly valve to be supposed to install the valve body in a high pressure side (axis to be in downriver).

1. Please read the warning ahead carefully.
  2. Main point: You should use the positioning device of handwheel or drive set to lock the butterfly valve position, not use the baffle plate To limit the stroke.
  3. When valve shutting down also the seat has compressed completely, inspect the disc position, the disc and the flange must Be parallel, and the error can't surpass 1./32 inch (0.79 millimeter).
  4. Before installing the valve to the pipeline, make sure that when rotate the handwheel and drive set at anti-clockwise direction(see from the upside), the valve is start to opening (see Fig.4A). Close the valve completely before installing.
  5. Pipeline: To prevent the disc bumps into the pipeline to damage the disc or the axis, the butterfly valve should install in pipeline flange center. The flange and pipeline welding must carry on before the valve installment. If can't, place the safety mask or the protecting screen between the valve and welding area before welding. To prevent to damage the valve seat, not only needs to protect valve to guard against the welding dregs, but also had prevented overheat. The welding dregs, welding rod, fragment, tool and so on must be eliminated from the pipeline before the Valve installment or transportation.
  6. Fixes the valve between the flanges, compresses the flange filling piece evenly, tightens the fastener in turn.
- Main point:** According to the corresponding pipeline standard, use suitable operating mode filling pieces and fixes the valve between the flanges by the fastener.
7. After the valve has installed, if the axis seal place has the leakage, the reason is the valve load on greater temperature change when transporting, in this situation, you only need adjust the packing to restore sealing property of the valve.

### 3 Maintenance

#### 3. 1 Outline

The conventional maintenance work is tightening packing clamp regularly, compensates the attrition of axis seal. However, the clamp can't press downward to tight excessively, otherwise will shrink the life of axis seals. The more widespread scope maintenance work, including replaces the valve seat and packing that you can see Explanation as below.

#### 3. 2 Disassemble valve

1. Please read the warning ahead **carefully**.
2. Dismount the valve from the pipeline, the valve must be closed completely.
3. Attention: If the valve drive set is spring to open (air to close), should separate the valve from the drive firstly, then close the valve. When disassemble the valve from the pipeline, the valve must be shutting down.

#### 4. 3 Valve seat replacement


1. Dismount the valve from the pipeline, and put to the worktable, please pay attention not to damage the seal edge of the butterfly Board.
2. Dismount insert bolts, take the clamping ring from the valve. If the clamping ring is not easy to take out, uses the wooden stick or the plastic stick and the hammer knocks it from a valve doorpost side. The hammer cannot directly knock on the valve. (Bolt fixed clamping ring: Causes the valve to be in the off-position, replaces the clamping ring and the valve seat together through the operation valve seat bolt. Evenly screws tight the bolt. Opens the valve, screw tight the valve seat bolt once more. Please pay attention not to damage the seal edge of the butterfly board. Close the valve.)
3. Dismantle the valve seat and abandon. Dismantle the valve body seal from the clamping ring and valve body.
4. Clean the contact gasket surface carefully with the suitable solvent, the surface should not have the scoop channel and the abrasion. If abrades deeply, should polish or must repair.




Unload the bolt on insert




If unloads the clamping ring with the bolt, the seat will abandonment



Installs the new seat seal




Place the seal in the valve seat



Stick the packing ring to the valve seat with the glue water




5. Clean the valve, removes the burr on the clamping ring.
6. Scour the butterfly board seal surface and polishes carefully. The surface should not have the scoop channel and the abrasion.
7. If the butterfly board packing surface has the slight abrasion, grind the packing surface with crocus cloth, close grained burr or similar polishes, if abrades deeply, need replace the butterfly board or Return to plant to maintenance.
8. Drive the valve to close.
9. Install the valve body seal filling gasket between the valve seat terminal and the valve body, sees chart 7. This valve use graphite filling gasket, the install method as follows:
  - A: The main point, pay attention not to damage the filling gasket, Otherwise can cause divulges.
  - B: The bottom plane of the clamp should not have the impurity, clean carefully with the appropriate.
  - C: Put the gasket into valve, if is lug type valve, please pay Attention to align the gasket hole and insert bolt.
10. Inspect the butterfly board whether in horizontal position. If is the horizontal position, installs the new clamping ring and the valve seat, see Figure 6 and 7, fixed inlays to the bolt, needs to install the clamping ring bolt, Please pay attention not to damage the seal edge of the butterfly board. Close the valve.
11. Adjust the drive localization according to the drive installment showing chapter. To replaces the valve seat, cannot install and screw tight the flange before the good drive localization and the entire closure. If the butterfly board position has not aimed, when screws tight the flange primary, may damage the new valve seat. Note: After installs the new Valve seat, some operating cycle torques may be bigger.



### 3.4 Replace axis seal

**Attention:** Please read the first page of prompt.

1. Dismantles the linkage of handwheel and drive set from the valve.
2. Dismantles the nuts for the gland, take down the clamp. Don't dismantle the bolt.
3. Takes down the old axis seal packing collar fragment, don't abrade the axis or the valve hole.
4. When replacing axis seal packing, don't dismantle the retainer.
5. Exchanges the new axis seal packing ring. Note: If the axis seal packing ring is a PTFE V type ring, keep the join together order when takes it out from the maintenance spare parts bag. Please pay attention to the direction on chart below, the direction is Suitable for the complete scope, including vacuum valve.




6. Reinstall the gland, the retaining ring, the clamp, the nut.

\* If the initial point of clamping ring hypothesizes too high, can't install the retaining ring, that must compress the axis seal ring firstly, then install the clamp, screw tightly the nut, caused the axis seal packing ring closely, after that dismantle the clamp, install the elastic ring, then assemble completely again.



Put the hoop into valve with starting bolt.




Screw the valve seat tightly with hexagonal head wrench.



Replace the valve seat completely



Dismount the gland



Dismount disc rivet



7. Close valve.

8. Close valve, screw the nut on packing clamp tightly, then compress the packing completely to prevent divulging. Compress completely means that after two nuts have contacts the clamp, the wrench Need twist 1 half to 2 rings.

### 3. 5 Valve disassemble

**Attention:** If must disassemble the valve completely, you'd better replace the valve seat and all seal rings.

1. Put the valve on the work table or other appropriate working areas.
2. If must replace the valve seat, please according to "the valve seat replacement" in the chapter 2, 3, 4 and the axis and the valve body seal and the bearing .
3. Defers to "the replacement, the axis seal packing " in the chapter on 1-4 step disassemble axis seal packing. If dismantles the axis from the valve firstly, disassemble packing material will be easier.
4. Remove the welding on disk pin with the methods of grinding or machining. Take the pin out on installment reverse direction. (See Figure 5).
5. Take down the nuts, cover board and gasket.
6. Dismantle the axis, please pay attention to not damage the butterfly board seal surface when takes the axis out from the butterfly board.
7. Take down the butterfly board, dismantle the thrust shaft and the under thrust bearing.
8. Take axle sleeve above out from the valve or get the axle sleeve lower out of the valve channel.

### 3. 6 Valve assembly

1. Clean the valve parts complete.
2. Before assembling the valve, should inspect all parts whether has the damage, check the damage situation of butterfly board, the axis and the valve body seal area as well as the bearing region attrition situation.
3. Scour the butterfly board seal surface and polishes carefully. The surface should not have the scoop channel and the abrasion.
4. If the butterfly board packing surface has the slight abrasion, grind the packing surface with crocus cloth, close grained burr or similar polishes, if abrades deeply, need replace the butterfly board or Return to plant to maintenance.
5. Put the axle sleeve in the valve body axis hole.
6. In order to install the axis on the butterfly board easily, if necessary, may spread the lubricant on the axis and butterfly board hole, the lubricant nature should be suitable to the medium which transports in the valve.
7. The axis passed through the axle sleeve, then installs the stop bearing, install the butterfly board to the flow channel, the butterfly board two slightly holes faces the valve cover, then passed the axis through the axis hole of the butterfly board, simultaneously put the thrust bearing under the butterfly board, cause the axis to pass through and the wrap enters the axle sleeve. Please pay attention to not damage the bearing and butterfly board seal surface.
8. Insert the pin into the butterfly board and knock it in according to the direction of chart 7, the depth of two pins must be same, indent do not surpass 1/16 '' (1.56mm). If the pin install correctly, the drive shaft shows on like chart 1 and chart 2, Then welds the beginnings and ends of the pin, welds a small end firstly, put the valve body on the log, after the butterfly board has cooled, brushes cleanly with the steel wire brush holder welding place Attention: when using, please not smear the valve.
9. If has the bearing retainer, then install it, the bevel edge side should face the butterfly board, then installs the top roll seal, the clamping ring, the retainer ring. If the axis seal packing is V type structure, must defer to chart 5 to install.
10. If the stud has already take down from the valve, install them in the hole which show to (chart 7) again, on the stud spreads Letai or other backing-up reagent. To prevent loosen when vibration. The



Dismount axis



Take axis seal out with the screw knife. Abandon



Insert axis



Change new axis seal



Compress the gland, complete the seal replacement

should stretch out, the stud of 2" (50.8mm), 10" and 12" (DN250 and 300) valve should stretch out 2-1/4 (57.15mm).

11. Installs the new gasket, fixes the cover board to valve body by the bolt. In order to guarantee the gasket load to be even, screws tight the bolt in turn.
12. If the handle localization toothed rack has already take down from the valve, install them which show to (chart 7) again, install the lock-packing ring and blot into the bonnet holes, after locate the handwheel position, screw tight the bolt. (See "handwheel locate position hypothesis" or drive installment explains" chapter).
13. Puts the clamp on the axis and the stud, then install the lock-nut, but don't screw tight.
14. Closes the valve completely, installs new valve seat and the body seals. The regulation sees "the valve seat replacement chapter".
15. Close valve, screw the nut on packing clamp tightly, then compress the packing completely to prevent divulging. Compress completely means that after two nuts have contacts the clamp, the wrench need twist 1 half to 2 rings.
16. According to "the setting handwheel locate position" chapter or "the drive installment explained" chapter, setting the handle or the drive locates position, then screws tight the bolt on the toothed Rack.

#### 4 Valve experiment procedure

If need carry on valve divulge experiment before the valve installs on the pipeline, should according to the following step:

1. In the following experiment, between the valve joint face and the test equipment should have the corresponding filling piece.
2. Before the valve pressurizes, guarantees all drive fastener is screws tight, the drive maintains the valve at the off-position under pressure. When the test pressure exerts to a butterfly board side, the valve biased design may be able to create it to revolve.
3. The valve should install between in the flanges or the test equipment, if uses the flange, refers to the 6th part of the chapter to install, if uses the test installment, the strength of the installment clamps must match with the valve flange bolt loaded.
4. Little open valve.confirm that no seal between seat with plate.avoid plate contact with testing jig,or else possible plate Breakage occurred.
5. Close the outlet of downstream,put pressure 100 Psi(6.9 bar) to valve.check shaft sealing and whether leakage occurredd from flange gasket.View bubble occurred or not after smear soapy Water to all the location of sealing connection.

The points of checking:please stop progress immediately if find leakage between valve with flange.to mark them on the leakage area. relieving valve pressure back till 0Psi(0bar),tighten flange bolts again.repress valve and check gasket.in case leakage there still,please disassemble valve and checking breakage.

6. In case the leakage occurred on the lacion of shaft sealing, please just tighten bonnect nuts.
7. Please relieving valve pressure continually,and close the valve when it's to 0Psi(0bar).
8. Connect tube or hose to downstream location of flange(which loated on the shaft side of valve).
9. Confirm that drive unit is with force/pressure.push pressure 100psi(6.9bar) on upstream flange(which located on insert side of valve)check whether leakage occurred from the dead end location Of ture/hose.
- 10.In case the leakage occurred,please relieving valve pressure to 0 Psi(0bar),and adjusting the close-stop of drive unit accords with related drive unit specification.
- 11.Repress valve and check leakage.in case leakage existing,please repeat the step 10 if leaking can't to be stop,adjust the position of Drive unit,reduce the leakage be least.
- 12.Might be small leakage occurred from the damaged plate of reassembled valve.put the dead end location of ture/hose into water, view bubble occurred or not in the case of it's n't other testing processing,check leakage after reached to stable

condition,cause the operating valve vent air,so for more minutes leakage to be stable or stop.to the condition of reassembled soft seal butterfly valve or fire proof butterfly vlave,it's acceptable that one bubble occurred from body port (25.4mm) by min/inch.

## 5 Drives installment explanatio

### 5. 1 Warning

Before install valve and actuator,please first confirm the positon indicator above actuator indicate position of valve correctly,in case parts in wrong fitting,wrong indicate position of valve,possible Induce bodily injury and death.

**Attention:**When install connector or maintenance valve/driving parts,best to disassemble whole driving set from equipment.

**Attention:**The disassembled driving set should reassembled to valve,please readjusting open and close correctly for every reassembling driving set.

**Attention:**The designment purpose of connector is that support weight of actuator and related accessories of HLV flow machine company,not available for equipment, people or ladder etc.or else destroy connector, valve or actuator,and possible bodily injury Occurred.

**Warning:**Installing actuator,please first confirm valve and driving lever on same location,in case fitting the open driving set on close valve, possible induce valve stem breakage.

**Remark:**Install single acting spring return pneumatic set on wafer valve,only available by spring close(air open) mode.







### 5. 2 Drive installment and adjustment

The setting precision of pneumatic actuator with valve,is much important to the actuator safe opearing and service life.for exact setting:putting the central axis of actuator absolute ganging with valve stem,testing the valve's torque to confirm it's working in the normative operating range before setting actuator to valve,after setting,to test pneumatic actuator with the valve simultaneously, exerting valve to reach the nominal sealing pressure value,for actuator,setting air pressure to be 0.4~0.7Mpa or by operating conditions.switching air supply between each of air inlets of actuator,to view valve's opening/closing situations,checking that shouldn't happened with dwell,stick-slip motion phenomena,and to repeat testing by several times.

Two setting modes for actuator with butterfly valve, 1.For rubber seal wafer butterfly valves with center line,the setting could to be finished by inserting into the shaft bore of pneumatic actuator. 2.For metal seal butterfly valves, which with different dimension stems producing by different manufacturers,the setting could to be finished by supports with connecting sleeve,attention to the axle housing shouldn't be higher than the depth of actuator's shaft bore to avoid top die happened working actuator out of action,the fitting accuracy between all the connectional parts should be enough of high,to avoid failed to open/close occurred leakage of valve, tolerance of fits which accords with the related standard,the fits tolerance of shaft bore with axle housing(stem), square hole with flat hole,and square head with f lat head accords with H11/d11 standard, the parallelism and symmetry accords with tolerance class 9 standard, the conventional flat key dimension and tolerance accords with GB/T1095-79 standard,the semicircular key dimension and tolerance accords with GB/T1098-79/GB/T1099-79 standard.

Adjusting and correcting the switch position after mounting by following the progress of sheet bellows,first of all,setting the position of butterfly valve to be close 3 and keeping the position of actuator piston in both side,then loose running fit the central nut of both sides cover of actuator, turn the tight screw to be adjusted enough(attention:it must keep safe by relieving actuator or cutting air supply.);adjusting the position 3 by clockwise mounting if the position is over and by anticlockwise mounting if it's not reach,switching air supply between each of air inlets of actuator, to view the position 3 situation,confirm the position 3 is correct after adjusting,finally tightening and sealing each sides nuts.

# Pneumatic actuator installation diagram




### 5. 3 Actuator type


It's popular that GT series 90 degree rotary pneumatic actuator and AW series 90 rotary pneumatic actuator which service in fluid industry.

#### 5. 3. 1 GT type series 90 rotary pneumatic actuator

GT type series pneumatic actuator compressed air transferred to power, by mechanical transmission of piston gear rack and gear, drive torque by angle travel, with features small in volume, light weight, and long life service. it's modern version actuator, with two mode about double acting and single acting spring return. served for angle travel control valve (ball valve, butterfly valve) in open/close and control.



Double acting type



Single acting type

Standard data		Special data
Basis designment	Pneumatic piston operator GTD type (double acting) GTE type (single acting with spring return)	Two special piston at three locations of actuator
The feature of manufacturing	Ultra-width face of gear rack (piston) and pinion transmission technology. The connection face for Piston, gear with housing produced by low-friction material Sliding bush bearing, guided. Single acting type security spring seat	
Adopted standard	Adopted standard The connection of actuator with valve Four or eight bolt holes accords with DIN/ISO 5211 Fitting hole of shaft accords with standard DIN 3337 The connection of actuator with control valve Accords with standard NUMUR VDI/VDE 3845, CTD/GTE040+090 Connection by patch panel Connection on actuator with signal box Accords VDI/VDE 3845	Several type of dimensions choosable to fitting shaft hole
Material of parts	Body: aluminum alloy face anodize End housing: aluminum alloy face powder coating Piston/gear rack: aluminum alloy O type sealing ring: buna-N rubber Bearing ring/ guide bushing: plastic	Outside shell and end housing: powder coating Special etch(ing) condition: optional stainless steel material Please feel free to contact us O type ring: fluororous rubber
Temperature of operating condition	-20~+90°C.	-40~+160°C.
Rotary angel	Double acting type=90° Single acting type=90°	Adjust the angle of rotary shaft of Standard actuator by each side clockwise rotation or anti-clockwise rotation by real conditions 0-45-90°, -60-120°, -90-180°, -120-240°, Please feel free to contact us.
Driving torque	3~10000Nm	
Air pressure	2~8bar, Max10bar.	
Accessories	solenoid valve, electric positioner, limited switch (mechanical, proximity type), triple parts for air supply processing (Filter reducing valve, filter-regulator, Oil atomizer), manual operator	Adjusting angle and ON/OFF cutting interlock device

## Selection of actuator

After definition torque value, increasing more 25% safety value for steam or non-lubricant liquid medium; increasing more 40% safety value for non-lubricant slurry liquid medium; increasing more 60% safety value for non-lubricant dry gas medium; increasing more 100% safety value for non-lubricant entrained powder medium which by gas transmission; increasing more 20% safety value for clean, non-friction lubricant medium. (recommended by HLV company)

Selection of double acting actuator that basing on the operating pressure of air supply against double acting type torque's sheet. instance one condition: air pressure 5 bar, controlling ball valve with operating torque 200N.m, medium non-lubricant steam, for safety factor, increasing more 25% safety value, then the torque should to be 250 N.m, First please check in the sheet, then find the equal torque value or close torque value which is working on the condition of air pressure 5 bar, so torque value 272 N.m is selected, finally choose the type GTD125 which met with the air pressure and selected torque.

Selection of single acting actuator that basing on the condition that air pressure torque value which more than spring return torque value, after get the tip of spring react against double acting type torque's sheet. instance one condition: air pressure 4 bar, controlling ball valve with operating torque 100N.m, medium non-lubricant dry gas, for safety factor, increasing more 60% safety value, then the torque should to be 160 N.m, First please check in the sheet, then find the close torque value 166 N.m by spring react destination, according with this data, then checked found the destination torque value 196 N.m which is working on the condition of air pressure 4 bar, and the air pressure torque is more than Spring react torque, finally choose the type GTE160 which met with the air pressure and selected torque.

## Fitting type

Basic position		The rotation direction of axis The position of top slot by looking down	The position of switch		sequence number
The position of rotation axis and piston by top perspective	The rotation direction of axis		The position of rotation axis and piston by top perspective	Fitting shaft bore by bottom	
	P			P	A
	D			D	B
	O			O	C
	P			P	D
	D			D	E
	O			O	F
	P			P	G
	D			D	H
	O			O	I
	P			P	K
	D			D	L
	O			O	M

Driving torque sheet of GTE double acting (unit)

Type	Air pressure (bar)						
	2	3	4	5	6	7	8
GTD40	3.7	5.6	7.4	9.3	11.2	13.0	14.9
GTD52	7.9	11.8	15.7	19.6	23.6	27.5	31.4
GTD65	14.7	22.1	29.5	36.8	44.2	51.5	58.9
GTD80	26.0	39.0	52.0	65.1	78.1	91.1	104
GTD90	37.6	56.5	75.3	94.1	112	131	150
GTD100	58.0	87.0	116	145	174	203	232
GTD115	84.5	126	169	211	253	295	338
GTD125	108	163	217	272	326	381	435
GTD145	159	239	318	398	478	557	637
GTD160	223	334	446	557	669	780	892
GTD190	367	550	734	917	1101	1284	1467
GTD210	538	807	1075	1344	1613	1882	2151
GTD255	1057	1586	2115	2644	3172	3701	4230
GTD300	1656	2470	3293	4117	4940	5764	6587
GTD350	2490	3735	4981	6226	7471	8717	9962




# Driving torque sheet of GTE double acting (unit) N . m

Type	Quantities of spring	Air pressure ( b a r )						Spring return	
		3		4		5			
		Inception	Tip	Inception	Tip	Inception	Tip	Inception	Tip
GTE65	8	15.0	7.9	22.3	15.2			14.2	7.1
	10			20.6	11.7	27.9	19.1	17.8	8.9
	12			18.8	8.1	26.2	15.5	21.3	10.7
GTE80	8	25.1	16.2	38.1	29.3			22.8	14.0
	10			34.6	23.6	47.6	36.6	28.5	17.5
	12			31.1	17.9	44.1	30.9	34.2	21.0
GTE90	8	32.8	20.9	51.6	39.8			35.5	23.7
	10			45.7	30.9	64.5	49.7	44.4	29.6
	12			39.8	22.0	58.6	40.8	53.3	35.5
GTE100	8	56.1	26.5	85.1	55.5			60.7	31.1
	10			77.3	40.3	106	69.4	75.9	38.9
	12			69.6	25.2	98.6	54.2	91.0	46.6
GTE115	8	77.9	45.4	120	87.6			81.4	48.8
	10			108	67.3	150	109	101	61.1
	12			95.8	46.9	138	89.2	122	73.3
GTE125	8	101	65.7	155	120			97.7	62.2
	10			140	95.7	194	150	122	77.7
	12			124	71.3	179	125	146	93.2
GTE145	8	135	83.7	215	163			155	103
	10			189	124	269	204	194	129
	12			163	85.7	243	165	233	155
GTE160	8	201	134	312	246			199	133
	10			279	196	391	307	249	166
	12			246	146	357	258	299	199
GTE190	8	317	213	500	397			336	233
	10			442	313	626	496	420	291
	12			384	228	567	412	505	349
GTE210	8	465	309	734	578			497	341
	10			648	454	917	723	621	427
	12			563	330	832	599	745	512
GTE255	8	945	670	1474	1199			915	640
	10			1314	970	1843	1499	1144	800
	12			1154	741	1683	1270	1373	961
GTE300	8	1491	838	2314	1662			1631	979
	10			2069	1254	2893	2077	2039	1223
	12			1825	846	2648	1669	2447	1468
GTE350	8	2181	1404	3427	2650			2330	1554
	10			3038	2067	4284	3312	2913	1942
	12			2650	1484	3895	2730	3496	2331

### The weight, volume, and open/close time of actuator

Double acting	Volume L	Weight K G	Single acting type	Volume L	Weight K G	Open or close time S
GTD40	0.12	0.7	GTE40	0.06	--	≤ 0.5
GTD52	0.23	1.5	GTE52	0.12	--	≤ 0.5
GTD65	0.46	2.0	GTE65	0.22	3.6	≤ 0.5
GTD80	0.80	3.0	GTE80	0.38	5.5	≤ 1.0
GTD90	1.10	4.5	GTE90	0.50	8.0	≤ 1.0
GTD100	1.60	6.0	GTE100	0.79	10.5	≤ 1.0
GTD115	2.33	8.0	GTE115	1.14	13.6	≤ 2.0
GTD125	3.03	9.5	GTE125	1.46	16.2	≤ 2.0
GTD145	5.40	14.0	GTE145	2.34	23.1	≤ 2.5
GTD160	6.10	18.0	GTE160	3.00	30.0	≤ 4.0
GTD190	11.0	26.0	GTE190	4.80	41.6	≤ 5.0
GTD210	15.4	33.0	GTE210	7.10	52.8	≤ 7.0
GTD255	31.1	72.0	GTE255	14.1	112.0	≤ 10.0
GTD300	45.9	102.0	GTE300	21.3	153.0	≤ 10.0
GTD350	68.5	153.0	GTE350	32.7	222.0	≤ 10.0

### Appearance and connection dimension drawing




# Appearance and connection dimensions

Actuator model	A	A1	B	C x Depth	D x Depth	E	F	G x Depth	H	J	K	L	M	N	P	Q	R <sup>H11</sup>	□ S x S	□ SW <sup>H11</sup>	T <sup>H9</sup>	U	V	W	Y <sub>Depth</sub>	Z <sup>H11</sup>
GTD/GTE040	104	—	45	8 x 12	M6 x 10	82	14	—	12	50.8	F04 Φ42	—	—	22	60	—	—	9 x 9	11 x 11	20	2.0	35	50		12
GTD/GTE052	140	—	50	8 x 12	M6 x 10	96	14	M5 x 8	16	3.0	50.8	F03 Φ36	F05 Φ50	22	74	14.2	12.7	10 x 10	11 x 11	23	2.0	35	62	32	12
GTD/GTE065	164	178	62	10 x 13	M8 x 13	102	16	M6 x 10	18	3.0	50.8	F05 Φ50	F07 Φ70	22	90	14.2	12.7	13 x 13	14 x 14	29	2.0	35	75	32	16
GTD/GTE080	190	214	65	10 x 15	M8 x 13	130	18	M6 x 10	18	5.0	50.8	F05 Φ50	F07 Φ70	22	108	18.4	15.88	13 x 13	17 x 17	33	2.0	35	91	32	16
GTD/GTE090	210	246	74	10 x 15	M8 x 13	140	18	M6 x 10	18	5.0	50.8	F05 Φ50	F07 Φ70	22	118	18.4	15.88	13 x 13	17 x 17	38	2.5	35	101	32	16
GTD/GTE100	247	295	90	14 x 22	M10 x 16	156	25	M8 x 13	24	5.0	50.8	F07 Φ70	F10 Φ102	22	134	21.6	19.05	16 x 16	22 x 22	46	2.5	35	112	45	22
GTD/GTE115	276	340	94	14 x 22	M10 x 16	177	25	M8 x 13	24	5.0	50.8	F07 Φ70	F10 Φ102	25	149	21.6	19.05	16 x 16	22 x 22	52	3.0	35	127	45	22
GTD/GTE125	308	398	103	20 x 24	M10 x 16	182	25	M8 x 13	30	5.0	50.8	F07 Φ70	F10 Φ102	25	160	24.8	22.23	22.3x22.3	22 x 22	55	3.0	35	139	45	30
GTD/GTE140	348	438	110	20 x 24	M12 x 16	216	29	M10 x 16	38	8.0	70.8	F10 Φ102	F12 Φ125	35	181	32.1	28.58	28.6x28.6	27 x 27	65	3.5	35	159	45	30
GTD/GTE160	378	478	110	28 x 30	M12 x 16	233	29	M10 x 16	38	8.0	70.8	F10 Φ102	F12 Φ125	35	198	32.1	28.58	28.6x28.6	27 x 27	70	3.5	35	176	45	42
GTD/GTE190	432	562	128	28 x 30	M12 x 16	282	29	M10 x 16	50	8.0	70.8	F10 Φ102	F12 Φ125	50	232	32.1	31.75	36 x 36	36 x 36	80	4.0	35	206	45	42
GTD/GTE210	524	724	135	32 x 34	M16 x 24	305	40	M16 x 24	50	8.0	150	F14 Φ140	160 x 100	50	255	35.3	31.75	36 x 3	36 x 36	92	4.0	60	228	45	48
GTD/GTE255	648	928	159	40 x 40	M20 x 24	352	50	M20 x 24	75	10	150	F16 Φ165	200 x 120	50	302	37.4	33.34	46 x 46	46 x 46	125	4.0	60	275	50	60
GTD/GTE300	715	1033	196	40 x 40	M20 x 24	400	50	M20 x 24	85	12	150	F16 Φ165	200 x 140	50	350	45.3	41.28	46 x 46	46 x 46	135	4.5	60	324	65	80
GTD/GTE350	795	1129	220	50 x 50	M20 x 24	458	70	M16 x 24	105	12	150	200	260 x 160	50	408	54.8	50.8	60 x 60	60 x 60	158	4.5	60	380	70	100

### 5. 3. 2 AP type series 90 degree (rotary) pneumatic actuator

AP type series pneumatic actuator have double acting and single acting (spring return), two split body cylinder, double piston, shifting fork type actuating mechanism, suitable for big size cylinder body, large driving torque, flexible and stable action; perfect wear-resistance, oilless lubricating bearings and guide rings are fitting with valve parts exchange based on reducing coefficient of friction, extending service life. The AW pneumatic actuator's driving torque with U type curve characteristic, is much suitable for large body size valves's open/close, adjusting, and 90 degree rotary service.



#### Standard data

Basis designment	Pneumatic double cylinder, double piston, shifting fork type actuating mechanism Model APxx=Double action type; Model APxxs=Single action type (spring-return) ;
Rotary degree	Double action type =90°; Single action type =90°; Valves's degree could to be adjusted from each side-5° ~+5° .
Working	-20°C~90°C。
Air supply	0.2~0.8MPa (Max1.0MPa) 。

#### Actuator's selection and installation

The points of selection AP pneumatic actuator: definition of valve's torque, medium, increasing more 25% safety value for steam or non-lubricant medium; increasing more 60% safety value for non-lubricant dry gas medium; increasing more 100% safety value for non-lubricant entrained powder medium which by gas transmission, increasing more 20% safety value for clean, non-friction lubricant medium, finally select actuator type that basing on the operating pressure of air supply against double acting or single acting type torque's sheet.


The setting precision of pneumatic actuator with valve, is much important to the actuator safe opearing and service life. for exact setting: putting the central axis of actuator absolute ganging with valve stem, testing the valve's torque to confirm it's working in the normative operating range before setting actuator to valve, after setting, to test pneumatic actuator with the valve simultaneously, exerting valve to reach the nominal sealing pressure value, for actuator, setting air pressure to be 0.4~0.7Mpa or by operating conditions. switching air supply between each of air inlets of actuator, to view valve's opening/closing situations, checking that shouldn't happened with dwell, stick-slip motion phenomena, and to repeat testing by several times.

#### The feature and purpose of actuator

Double acting pneumatic actuator: ON/OFF control to valve's open/close

Spring return type: Automatic opening or closing valves sevicig to the situations when the circuit is cut or failed.

## Yoke Movement Simulation




## Double action Output torque

Model	Double action Output torque				
	Air supply(Mpa)				
	0.3	0.4	0.5	0.6	0.7
AP A16	723	964	1205	1446	1687
AP A20	1130	1507	1884	2260	2637
AP B20	1695	2260	2826	3391	3956
AP B25	2649	3532	4415	5298	6181
AP B28	3323	4430	5538	6646	7753
AP C28	4615	6154	7693	9231	10770
AP C35	7212	9616	12020	14424	16828
AP C40	9420	12560	15700	18840	21980
AP C45	11922	15896	19870	23844	27818



## Single action type Output torque

Model	Spring torque		Air supply (Mpa)					
			0.4		0.5		0.6	
	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.
AP A25S	106	1618	736	1148	1325	1734	1913	2325
AP A28S	1513	2031	922	1440	1661	2179	2399	2917
AP B28S	2270	3043	1387	2160	2492	3267	3603	4376
AP B35S	3547	4759	2164	3374	3895	5107	5625	6837
AP C35S	4928	6610	3006	4688	5409	7092	7814	9496
AP C40S	8146	10928	4968	7750	8941	11723	12916	15698
AP C50S	9812	13246	5594	9028	10304	13738	15014	18448


## Symmetrical & Canted Torqu



**CANTED**



**SYMMETRIC**



Jackscrew OVERRIDE




Gear override




Hydraulic override




## Dimensions(Dual role)




External dimensions and connection dimensions																
Model	L	G	M1	M2	$\Phi C$	$\Phi D$	H	B	T	$\Phi d$	$\Phi d1$	b	b1	b2	Z-M1	Air connection
AP A16	786	206	85	132	174	45	42	14	48.8	140	/	144	72	76	4-M16	G 1/4
AP A20	786	203	85	132	214	45	42	14	48.8	140	/	144	72	76	4-M16	G 1/4
AP B20	1058	218	105	206	214	60	52	18	64.4	200	232	/	/	/	8-M16	G 3/8
AP B25	1058	218	105	206	266	60	52	18	64.4	200	232	/	/	/	8-M16	G 3/8
AP B28	1058	218	105	206	296	70	52	22	75.4	200	232	/	/	/	8-M16	G 3/8
AP C28	1360	260	140	300	296	100	106	28	106.4	300	350	/	/	/	8-M24	G 1/2
AP C35	1360	260	140	300	370	100	106	28	106.4	300	350	/	/	/	8-M24	G 1/2
AP C40	1360	260	140	300	420	100	106	28	106.4	300	350	/	/	/	8-M24	G 1/2
AP C45	1360	260	140	300	470	100	106	28	106.4	300	350	/	/	/	8-M24	G 1/2




## Dimensions(Single)



External dimensions and connection dimensions																	
Model	L	L1	G	M1	M2	$\Phi C$	$\Phi D$	H	B	T	$\Phi d$	$\Phi d1$	b	b1	b2	Z-M1	Air connection
AP A25S	1396	393	203	85	132	266	45	42	14	48.8	140	/	144	72	76	4-M16	G 1/4
AP A28S	1396	393	203	85	132	296	45	42	14	48.8	140	/	144	72	76	4-M16	G 1/4
AP B28S	1945	529	218	105	206	296	60	52	18	64.4	200	232	/	/	/	8-M16	G 3/8
AP B25	1945	529	218	105	206	370	60	52	18	64.4	200	232	/	/	/	8-M16	G 3/8
AP C35S	2040	680	260	140	300	370	100	106	28	106	300	350	/	/	/	8-M24	G 1/2
AP C40S	2040	680	260	140	300	420	100	106	28	106	300	350	/	/	/	8-M24	G 1/2
AP C45S	2040	680	260	140	300	470	100	106	28	106	300	350	/	/	/	8-M24	G 1/2
AP C50S	2040	680	260	140	300	520	100	106	28	106	300	350	/	/	/	8-M24	G 1/2



## Materials of Construction




Part No.	Q' ty	Description	Standard Material	Remark
01-0	1	Housing	Ductile Iron	
01-1	2	Housing Pin	Carbon Steel	
02-0	1	Worm Gear	Ductile Iron	
02-1	2	O-Ring	NBR	
03-0	1	Thrust Bearing	Aluminum Bronze	
04-0	1	Decl. Cam Bush	Brass	
04-1	1	O-Ring	NBR	
04-2	1	O-Ring	NBR	
05-0	1	Worm Wheel	Carbon Steel	
05-1	2	Pin	Carbon Steel	
06-0	2	Thrust Ball Bearing	Bearing Steel	
07-0	1	Shaft	Carbon Steel	
07-1	1	Snap Ring	Plated Carbon Steel	Fb048 above not applicable
08-0	1	Side Cover	Plated Carbon Steel	
08-1	4	Side Cover Bolt	Carbon Steel	
09-0	1	Position Adapter	Carbon Steel	
10-0	1SET	Position Lever Assy	Stainless Steel & Plastic	
11-0	1SET	Position Lock Assy	Carbon Steel & Plastic	
12-0	1	Gasket	Paper	
13-0	1	Cover	Ductile Iron	
13-1	6	Cover Bolt	Carbon Steel	FB032 (4)
14-0	2SET	Adjustment Bolt & Nut	Carbon Steel	
15-0	1	Coupling	Carbon Steel	Plated
15-1	1	Key	Carbon Steel	
16-0	1	Handwheel	Ductile Iron / Carbon Steel	Powder Coating
17-0	1	Washer	Carbon Steel	Plated
17-1	1	Bolt	Stainless Steel	

## Performance Data


Model	Gear Ratio	Mechanical Advantage	Weight		Maximum input Torque		Output Torque with 80Lbs		Maximum output Torque		Valve Mounting Size	Actuator Mounting Size
			kgs	pounds	Nm	psig	Nm	psig	Nm	psig		
FB032-DGO	32 : 1	8 : 1	8	17	70	619	225	1991	294	2602	F05 / F07	F05 / F07
FB036-DGO	36 : 1	9 : 1	15	33	105	929	428	3788	558	4938	F05 / F10	F07 / F10
FB048-DGO	48 : 1	12 : 1	26	57	123	1088	740	6549	911	8063	F10 / F12	F10 / F12
FB064-DGO	64 : 1	16 : 1	46	101	158	1398	1397	12364	1675	14825	F12 / F14	F12 / F14
FB080-DGO	80 : 1	20 : 1	63	138	211	1867	2328	20604	2822	24976	F14 / F16	F14 / F16
FB096-DGO	96 : 1	24 : 1	118	249	282	2495	4064	35969	4860	43014	F16 / F25	F16 / F25

## Dimensions

### FB032-DGO to FB048-DGO



### FB064-DGO to FB096-DGO



## Dimensions

(Unit : mm)

Model	A	B	C	D	E	F	G	H	I	J	$\square K$
FB032-DGO	98	167	55	76	104	38	55	185	43	200	17
FB036-DGO	125	194	69	91	132	47	71	213	53.5	300	22
FB048-DGO	160	243	79	123	156	54	84	247	74.5	350	27
FB064-DGO	220	296	96	157	193	71	121	282	106	450	36
FB080-DGO	267	362	120	197	225	86	148	330	133.5	600	46
FB096-DGO	340	458	170	244	254	92	192	413	172.5	800	55

Model	L	M-N	O	P-Q	R	S	$\square T$	U-V	W	X-Y	Z
FB032-DGO	22	4-M6X10	50	4-M8X12	70	17	17	4- $\phi 7$	50	4- $\phi 9$	70
FB036-DGO	27	4-M8X12	70	4-M10X15	102	22	22	4- $\phi 9$	70	4- $\phi 12$	102
FB048-DGO	32	N/A	N/A	4-M12X18	125	27	27	N/A	N/A	4- $\phi 14$	125
FB064-DGO	42	N/A	N/A	4-M16X24	140	36	36	N/A	N/A	4- $\phi 19$	140
FB080-DGO	53	N/A	N/A	4-M20X30	165	46	46	N/A	N/A	4- $\phi 23$	165
FB096-DGO	60	N/A	N/A	8-M16X24	254	55	55	N/A	N/A	8- $\phi 19$	254

## Instruction of MIR series installment, service and use



Canada HLV Flow Machinery Corporation  
[Http://www.hlvflow.com](http://www.hlvflow.com)

ADD: 54-4936 Dalton Drive NW  
Calgary, Alberta Canada T3A2E4

TEL: (403)390-3406

FAX: (403)286-8868

